

Package ‘kwb.hantush’

September 17, 2019

Title Calculation of Groundwater Mounding Beneath an Infiltration Basin

Version 0.3.0

Description Calculation groundwater mounding beneath an infiltration basin based on the Hantush (1967) equation (<doi:10.1029/WR003i001p00227>). The correct implementation is shown with a verification example based on a USGS report (page 25, <<https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf#page=35>>).

License MIT + file LICENSE

URL <https://kwb-r.github.io/kwb.hantush>,
<https://github.com/KWB-R/kwb.hantush>

BugReports <https://github.com/KWB-R/kwb.hantush/issues>

Depends R (>= 3.0), lattice

Imports hydroGOF

Suggests testthat, knitr, rmarkdown

VignetteBuilder knitr

Encoding UTF-8

Language en-US

LazyLoad yes

RoxygenNote 6.1.1

NeedsCompilation no

Author Michael Rustler [aut, cre] (<<https://orcid.org/0000-0003-0647-7726>>),
Kompetenzzentrum Wasser Berlin gGmbH [cph]

Maintainer Michael Rustler <michael.rustler@kompetenz-wasser.de>

Repository CRAN

Date/Publication 2019-09-17 09:30:03 UTC

R topics documented:

baseProperties	2
baseProps_ex1	3
compareModelResults	3
erf	4
example1	4
getModelComparisonTable	5
hantush	6
hantushDistances	7
hantushDistancesBaseProps	7
hantushS	8
hantushSstar	9
plotModelComparison	10

Index	11
--------------	-----------

baseProperties	<i>Hantush equation base properties</i>
----------------	---

Description

Hantush equation base properties

Usage

```
baseProperties(time = 10, basinWidth = 10, basinLength = 10,
  infiltrationRate = 0.5, horizConductivity = 10, iniHead = 10,
  specificYield = 0.2, numberTimeSteps = 150)
```

Arguments

time	time elapsed since recharge began (T), (Default: 1.5 days)
basinWidth	half width of the recharge basin (L), (Default: 10 m)
basinLength	half length of the recharge basin (L), (Default: 10 m)
infiltrationRate	recharge (infiltration) rate (L/T), (Default: 0.5 m/d)
horizConductivity	horizontal hydraulic conductivity (L/T), (Default: 10 m/d)
iniHead	initial head (height of the water table above the base of the aquifer);(L), (Default: 10)
specificYield	specific yield (Default: 0.2)
numberTimeSteps	number of time steps to be used for average aquifer thickness calculation (Default: 150)

Value

Base properties for Hantush equation

References

p.22, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

baseProps_ex1

USGS verification example: base parameterisation

Description

USGS verification example

Usage

baseProps_ex1()

References

p.23, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

compareModelResults

USGS verification example: compare R results for water level increase with other models and calculate statistical goodness of fit values (e.g. RMSE, PBIAS, NSE)

Description

USGS verification example: compare R results for water level increase with other models and calculate statistical goodness of fit values (e.g. RMSE, PBIAS, NSE)

Usage

compareModelResults(conf = example1())

Arguments

conf list as retrieved by example1()

Value

data.frame with R results and other model including all goodness of fit criteria calculated with gof() of package hydrogof

References

Table 5, p.25, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

See Also

[example1](#) for the USGS example parameterisation with distances

erf	<i>Error function</i>
-----	-----------------------

Description

Error function

Usage

erf(x)

Arguments

x	x
---	---

Value

Error function result

References

<https://stat.ethz.ch/R-manual/R-devel/library/stats/html/Normal.html>

example1	<i>USGS verification example: model parameterisation (multiple distances)</i>
----------	---

Description

USGS verification example: model parameterisation (multiple distances)

Usage

```
example1(x = c(0, 0.3, 3.3, 6.6, 10, 20, 25, 30, 40, 50, 75, 100, 150,
  200), baseProps = baseProps_ex1(), dbg = FALSE)
```

Arguments

x	distance from the center of the recharge basin in the x direction (L)
baseProps	basic model properties as retrieved by baseProps_ex1()
dbg	If True additional messages on debug messages

References

p.23, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

Examples

```
res <- example1()
if (FALSE) {
  ##### Head for each time step (defined with parameter "numberTimeSteps")
  xyplot(head ~ x | as.factor(sprintf("%f days", timeSteps)),
    data = res$timeSteps,
    type = "b",
    las = 1,
    as.table = TRUE
  )
  ##### Head at end of simulation
  plot(head ~ x,
    data = res$simTime,
    type = "b",
    las = 1
  )
}
##### Water level increase at end of simulation & compare to alternative models
modelComparison <- compareModelResults(conf = res)
plotModelComparison(modelComparison = modelComparison)
```

getModelComparisonTable

USGS verification example: get model comparison table

Description

USGS verification example: get model comparison table

Usage

```
getModelComparisonTable()
```

Value

data.frame with water level increase of different model approaches

References

Table 5, p.25, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

Examples

```
modelComparison <- getModelComparisonTable()
```

hantush

Hantush equation

Description

Hantush equation

Usage

```
hantush(x = 0, y = 0, baseProps = baseProperties(), dbg = TRUE)
```

Arguments

x	distance from the center of the recharge basin in the x direction (L)
y	distance from the center of the recharge basin in the y direction (L)
baseProps	basic model properties as retrieved by baseProperties()
dbg	If True additional messages on integration quality of function hantushSstar are printed on screen

Value

Head at a given time after recharge begins

References

p.22, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

See Also

[baseProperties](#) for basic model properties

hantushDistances *Hantush distance: for multiple coordinates*

Description

Hantush distance: for multiple coordinates

Usage

```
hantushDistances(x = 0:10, y = rep(0, length(x)),
  baseProps = baseProperties(), dbg = TRUE)
```

Arguments

x	vector with distances from the center of the recharge basin in the x direction (L), (Default: each meter between 0-100m)
y	vector with distances from the center of the recharge basin in the y direction (L), (Default: 0 times length of x)
baseProps	basic model properties as retrieved by baseProperties()
dbg	If True additional debug messages are printed on screen

Value

Head at a given time after recharge begins

See Also

[hantush](#) for parameterizing the Hantush equation

hantushDistancesBaseProps

Hantush distances & base properties: allows input of vector of x,y coordinates and also a vector for one of the base properties

Description

Hantush distances & base properties: allows input of vector of x,y coordinates and also a vector for one of the base properties

Usage

```
hantushDistancesBaseProps(x = seq(0, 200, 5), y = rep(0, length(x)),
  baseProps = baseProperties(time = 2^(0:6), infiltrationRate = 1,
  basinWidth = 10, basinLength = 50, horizConductivity = 10, iniHead = 10,
  specificYield = 0.2), dbg = FALSE)
```

Arguments

x	vector with distances from the center of the recharge basin in the x direction (L), (Default: every 5 meter between 0-200m)
y	vector with distances from the center of the recharge basin in the y direction (L), (Default: 0 times length of x)
baseProps	as retrieved by baseProperties(), but one property is allowed to be a vector (e.g. infiltrationRate = c(1,2,4))
dbg	If True additional debug messages are printed on screen

Value

List with sublists "dat" (x,y,head & WLincrease), "changedBaseProp.Name" (name of base property with multiple values) and "baseProps" (complete base parameterisation)

See Also

[baseProperties](#) for basic model properties

Examples

```
baseProps <- baseProperties(
  time = 2^(0:6),
  infiltrationRate = 1,
  basinWidth = 10,
  basinLength = 50,
  horizConductivity = 10,
  iniHead = 10,
  specificYield = 0.2,
  numberTimeSteps = 10
)
res <- hantushDistancesBaseProps(baseProps = baseProps)
cols <- length(unique(res$dat[[res$changedBaseProp.Name]]))
mainTxt <- sprintf("Changed baseProperty: %s", res$changedBaseProp.Name)
xyplot(WLincrease ~ x,
  groups = res$dat[[res$changedBaseProp.Name]],
  data = res$dat,
  type = "b",
  auto.key = list(columns = cols),
  main = mainTxt
)
```

hantushS

Helper function hantushS

Description

Helper function hantushS

Usage

hantushS(x, alpha, beta)

Arguments

x	distance between 0 and half length of recharge basin
alpha	alpha
beta	beta

Value

Hantush star

References

p.22, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

hantushSstar	<i>Hantush function Sstar</i>
--------------	-------------------------------

Description

Hantush function Sstar

Usage

hantushSstar(alpha, beta, dbg)

Arguments

alpha	alpha
beta	beta
dbg	If True additional messages on integration quality of function hantushSstar are printed on screen

Value

Hantush Sstar result

References

p.22, <https://pubs.usgs.gov/sir/2010/5102/support/sir2010-5102.pdf>

plotModelComparison *USGS verification example: plot model comparison results*

Description

USGS verification example: plot model comparison results

Usage

```
plotModelComparison(modelComparison = compareModelResults(),  
  title = "", ...)
```

Arguments

modelComparison	data.frame as retrieved by compareModelResults(), Default: (compareModelResults())
title	to be used as title above plot (Default: "")
...	further arguments passed to function xyplot()

Value

model comparison goodness of fit plots

See Also

[compareModelResults](#) for comparison with USGS benchmark models

Examples

```
### Plot model comparison with title "Model comparison" and one plot for  
### each page  
plotModelComparison(  
  title = "Model comparison",  
  layout = c(1, 1)  
)
```

Index

baseProperties, [2](#), [6](#), [8](#)
baseProps_ex1, [3](#)

compareModelResults, [3](#), [10](#)

erf, [4](#)
example1, [4](#), [4](#)

getModelComparisonTable, [5](#)

hantush, [6](#), [7](#)
hantushDistances, [7](#)
hantushDistancesBaseProps, [7](#)
hantushS, [8](#)
hantushSstar, [9](#)

plotModelComparison, [10](#)